

## Tips and Techniques

### Installing Viper® Landscape Edging.



Viper® Landscape Edging

- extra heavy top U.V. protected LDPE plastic
- unique corrugated design for ultimate holding power
- withstands frost heave
- used by professional landscape contractors
- handles the toughest landscaping jobs



If your edging comes coiled, lay the coil out in the sun, this will warm the plastic and make the edging more flexible to work with. Warning: If you place the coiled edging on grass, it will attract the hot sun and heat the grass beneath. This will ultimately kill the underlying grass. No more than 20 minutes on the grass if it is a hot sunny day.



Have a plan. Take a rope or garden hose and lay it out where you plan to install the edging.



Trench approximately 4-5" depending on the type of edging you use.



"T" design at the bottom acts as an anchor. The corrugated sides keep Viper edging in the ground. No staking is necessary when using Viper. Most other edging types do require stakes.



For ultimate connection, cut the top tube and one side of the "T" approximately 6"



Slide the "T" down into the ground and connect them together so the tube and the coupler connect together for a tight fit.

These are helpful techniques suggested by Master Mark Plastics. Other techniques can be used. Use your judgement when installing.



[Close Window](#)